

Product note

Gear cutting unit, adjustable angle

Face contact flat

Note on applicability Illustrations in this publication may deviate from the product supplied. Errors and ommissions due to technical progress expected. A word on copyright

This document is protected by copyright and was originally compiled in German.

The duplication and distribution of this document or parts thereof is prohibited without price.

The duplication and distribution of this document or parts thereof is prohibited without prior consent of the copyright owner, and any violators will be prosecuted. All rights, including the right to translate, are reserved.

© Copyright by INDEX-Werke GmbH & Co. KG




Gear cutting unit, adjustable angle

Face contact flat

Presetting

- · Presetting is done outside the tool holder, to achieve a play-free fit in the bearings
- Assemble ring (A), taper (B) and clamping sleeves (C)
- Use cylinder head screw (D) to tighten the mounting arbor (E)
- Adjust the required outside diameter 17mm+0.004 by ginding the ring (A)
- Disassemble again for installation in the gear cutting unit






Gear cutting unit, adjustable angle

Face contact flat

Installation

- Tighten mounting arbor (E) and inserted gear cutter (Y) with cylinder head screw (Z) to 20Nm
- Secure plate (F) with oval head screw (G) to housing (H)
- Assemble cover (I) and housing (H)
- Insert into gear cutting unit (J)
- Observe face contact (K) of the housing (H) during installation
- Use plate (F) as lateral stop
- Tighten cylinder head screw (D)
- Tighten cylinder head screws (L)






Gear cutting unit, adjustable angle

Face contact flat

Angle adjustment

- Adjust the angle and speed as instructed by the manufacturer of the gear cutters
- Angle adjusting screw (W) is used for coarse adjustment
- Angle is adjusted when installed in the machine on the ground measuring surface (M)



INDEX TRAUB

INDEX TRAUB



INDEX-Werke GmbH & Co. KG Hahn & Tessky

Plochinger Straße 92 D-73730 Esslingen

Fon +49 711 3191-0 Fax +49 711 3191-587

info@index-werke.de www.index-werke.de