

## Product note

**Mounting 11008063**  
**TRAUB TNL 18, TRAUB TNL 20**

**Mounting 10826369**  
**TRAUB TNL 32**

## **Note on applicability**

Illustrations in this publication may deviate from the product supplied. Errors and omissions due to technical progress expected.

## **A word on copyright**

This document is protected by copyright and was originally compiled in German.


The duplication and distribution of this document or parts thereof is prohibited without prior consent of the copyright owner, and any violators will be prosecuted. All rights, including the right to translate, are reserved.

© Copyright by INDEX-Werke GmbH & Co. KG

<b>Mounting and preadjustment block .....</b>	<b>4</b>
<b>Adjusting the mounting scale .....</b>	<b>5</b>
<b>Zero points with compact shank D45mm .....</b>	<b>6</b>
<b>Zero points with shank D36mm .....</b>	<b>7</b>
 <b>Application example Tool holder system TRAUB compact shank D45</b>	
X-axis, grooving tool holder, measure tool tip .....	8
X-axis, turning tool holder, measure tool tip .....	9
X-axis, triple turning tool holder, measure tool tip .....	10
X-axis, radius measurement, triple turning tool holder, measure tool tip .....	11
X-axis, base holder with mounting D24, measure tool tip .....	12
Y-axis, turning tool holder, measure tool tip .....	13
Y-axis, triple turning tool holder, measure tool tip .....	14
Y-axis, base holder with mounting D24, measure tool tip .....	15
Z-axis, turning tool holder, measure tool tip .....	16
Z-axis, turning tool holder, turning towards counter spindle, measure tool tip .....	17
Z-axis, base holder with mounting D24, measure tool tip .....	18
Z-axis, triple base holder, measure tool tip .....	19
 <b>Application example Tool holder system TRAUB shank D36</b>	
X-axis, base holder with mounting, measure tool tip .....	20
Y-axis, base holder with external turning tool, measure tool tip .....	21
Y-axis, milling unit, measure tool tip .....	22
Z-axis, base holder with internal turning tool, measure tool tip .....	23

## Mounting and preadjustment block

For more information on the preadjustment block, see product information W9800003EN.  
It contains a short description and instructions on installing and removing the counter-weights and the mounting.




## Adjusting the mounting scale



The drawing shows the mounting 11008063 for TRAUB TNL 18, TNL 20 with design date from 01.2014, the scale must be adjusted also for mounting 10826369 for TRAUB TNL 32.

### Adjustment

- Install mounting (2) in preset block (6), refer to product note W9800003EN for instructions
- Run dial gauge (1) along surface and align the mounting (2)



- Loosen both cylinder head screws (3) of the mounting (2)
- Align the scale plate (4) of the mounting (2) to the scale (5) the preset block (6)
- Loosen both cylinder head screws (3) of the mounting (2)




## Zero points with compact shank D45mm

The drawing shows the mounting 11008063 for TRAUB TNL 18, TNL 20 with design date from 01.2014, the scale adjustment can be used also for mounting 10826369 for TRAUB TNL 32.


### Determining the zero point on the X-axis

- Area measurement (1), the measured value is a radius value, for entering into the tool memory, this value must be doubled
- Radius measurement (2), the measured value is a radius value, 40 mm must be subtracted, for entering into the tool memory, this value must be doubled






### Determining the zero point on the Y-axis

- Select depending on the mounting position (1, 2)



### Determining the zero point on the Z-axis

- Turning towards main spindle (1)
- Turning towards counter spindle (1)
- Turning towards main spindle (2)  
Tool holders with machining towards the main spindle can partly not be measured in the correct mounting position.  
In this case, the sign of the measured value must be inversed.




## Zero points with shank D36mm

The drawing shows the mounting 11008063 for TRAUB TNL 18, TNL 20 with design date from 01.2014, the scale adjustment can be used also for mounting 10826369 for TRAUB TNL 32.


### Determining the zero point on the X-axis

- For internal turning tools (1)
- For external turning tools (2), the measured value is a radius value, for entering into the tool memory, this value must be doubled




### Determining the zero point on the Y-axis

- Select depending on the mounting position (1, 2)



### Determining the zero point on the Z-axis

- Area measurement (1)



#### Product note



Mountings 11008063, 10826369  
W9800006EN-18.03.19

## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### X-axis, zero point setting



#### X-axis, grooving tool holder, measure tool tip



The measured value is a radius value,  
for entry into the tool memory, this value must be doubled





## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### X-axis, zero point setting



#### X-axis, turning tool holder, measure tool tip



The measured value is a radius value,  
for entry into the tool memory, this value must be doubled

#### Product note



Mountings 11008063, 10826369  
W9800006EN-18.03.19

## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### X-axis, zero point setting



#### X-axis, triple turning tool holder, measure tool tip



The measured value is a radius value,  
for entry into the tool memory, this value must be doubled





## Application example


### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

### X-axis, radius measurement, zero point setting



### X-axis, radius measurement, triple turning tool holder, measure tool tip



The measured value is a radius value; 40 mm must be subtracted for 11008063 (75 mm for 10826369), for entering into the tool memory, this value must be doubled

#### Product note



Mountings 11008063, 10826369  
W9800006EN-18.03.19

## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### X-axis, zero point setting



#### X-axis, base holder with mounting D24, measure tool tip



The measured value is a radius value,  
for entry into the tool memory, this value must be doubled





## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Y-axis, zero point setting



#### Y-axis, turning tool holder, measure tool tip



#### Product note



Mountings 11008063, 10826369  
W9800006EN-18.03.19

## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Y-axis, zero point setting



#### Y-axis, triple turning tool holder, measure tool tip







## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Y-axis, zero point setting



#### Y-axis, base holder with mounting D24, measure tool tip



#### Product note



Mountings 11008063, 10826369  
W9800006EN-18.03.19

## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Z-axis, zero point setting



#### Z-axis, turning tool holder, measure tool tip







## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Z-axis, zero point setting, turning towards counter spindle



#### Z-axis, turning tool holder, turning towards counter spindle, measure tool tip



#### Product note



Mountings 11008063, 10826369  
W9800006EN-18.03.19

## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Z-axis, zero point setting



#### Z-axis, base holder with mounting D24, measure tool tip







## Application example



### Tool holder system TRAUB compact shank D45

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Z-axis, zero point setting



#### Z-axis, triple base holder, measure tool tip



Tool holders with machining towards the main spindle partially cannot be measured in the correct installation position. In this case, the sign of the measured value must be inversed: + becomes - and - becomes +.

#### Product note



Mountings 11008063, 10826369  
W9800006EN-18.03.19

## Application example


### Tool holder system TRAUB shank D36

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### X-axis, zero point setting



#### X-axis, base holder with mounting, measure tool tip



The measured value is a radius value,  
for entry into the tool memory, this value must be doubled





## Application example



### Tool holder system TRAUB shank D36

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Y-axis, zero point setting



#### Y-axis, base holder with external turning tool, measure tool tip



#### Product note



Mountings 11008063, 10826369  
W9800006EN-18.03.19

## Application example



### Tool holder system TRAUB shank D36

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Y-axis, zero point setting



#### Y-axis, milling unit, measure tool tip





## Application example


### Tool holder system TRAUB shank D36, with mounting 11008063

Mounting 11008063 shown with design date up to 12.2013, valid also for 10826369

#### Z-axis, zero point setting



#### Z-axis, base holder with internal turning tool, measure tool tip



#### Product note

Mountings 11008063, 10826369  
W9800006EN-18.03.19





**INDEX-Werke GmbH & Co. KG**  
**Hahn & Tessky**

Plochinger Straße 92  
D-73730 Esslingen

Fon +49 711 3191-0  
Fax +49 711 3191-587

[info@index-werke.de](mailto:info@index-werke.de)  
[www.index-werke.de](http://www.index-werke.de)