

INDEX

TRAUB



INDEX MS22-6

Tool holder

Technical Information

better.parts.faster.

Note on applicability

Illustrations in this publication may deviate from the product supplied. Errors and omissions due to technical progress expected.

A word on copyright

This document is protected by copyright and was originally compiled in German.

The duplication and distribution of this document or parts thereof is prohibited without prior consent of the copyright owner, and any violators will be prosecuted. All rights, including the right to translate, are reserved.

© Copyright by INDEX-Werke GmbH & Co. KG

Technical Information	5
Tool holder selection	5
Warranty	5
Information on wear parts.....	5
Inspection of live tool holders.....	5
Tool holders with cooling lubricant supply.....	6
Cooling lubricant filtering	6
Cleaning live tool holders.....	6
Speed ratio specifications on tool holders	6
Direction of rotation specification	7
Tightening torque	8
Replacement seals for tool shank	8
Tool holders with fixation	9
Load limits of live tools	9
Notes on how to use the chart when using tool holders	10
Usage information	11
Machine concept of the INDEX MS22-6	11
Full equipment with one synchronous spindle.....	11
Full equipment with two synchronous spindles.....	12
Travel of cross slide unit INDEX MS22-6.....	13
Cross slide unit X-NC 1.1 - 6.2	13
Cross slide unit X-rigid 1.1, 1.2, 2,1	14
Travel of cross slide unit INDEX MS22-6.....	15
Cross slide unit X-hydraulic 1.1, 1.2, 2,1	15
Synchronized spindle INDEX MS22-6.....	16
Synchronous spindle with parts removal 6.1, 5.2	
Rear end machining unit on cross slide unit 6.2, 6.3, 5.1, 5.3	16
Y axis INDEX MS22-6	18
Attachable to cross slide unit 3.1, 4.1, 5.1	18
Tool drive unit shank VDI20, INDEX MS22-6.....	19
Cross slide unit 1.1 - 6.2	19
Installation size.....	19
Tool drive unit shank VDI25, INDEX MS22-6.....	21
Cross slide unit 1.1 - 6.2	21
Installation size.....	21
Cross slide unit INDEX MS22-6.....	23
X-NC 1.1 - 6.2	23
Modular design of INDEX MS22-6.....	24
Grooving tool holder	24
Cross slide unit 1.1 - 6.2, machining in X/Z direction.....	24
Base holder with drill holder D28,5mm.....	25
Cross slide unit 1.1 - 6.2, machining in X/Z direction.....	25
Milling tool holder	26
Cross slide unit 1.1 - 6.2, machining in X/Z direction.....	26

Milling unit, shank HSK25C	27
Cross slide unit 1.1 - 6.2, machining in X/Z direction.....	27
Tool drive unit, shank VDI20/VDI25	28
Cross slide unit 1.1 - 6.2, machining in X/Z direction.....	28
Polygon turning unit	29
Cross slide unit 1.1 - 6.2, machining in X/Z direction.....	29
Rear end machining unit, rigid	30
Cross slide unit 6.2/5.1, machining in X/Z direction.....	30
Rear end machining unit	31
Cross slide unit 5.3/6.3, machining in X/Z direction.....	31
Performance diagram.....	32
Tool drive unit VDI20/VDI25, i=1	32
Milling unit transverse HSK25C, i=0,5	33
Milling unit axis-parallel, HSK-25C, i=0,59375	
Milling unit angle-adjustable, HSK-25C, i=0,6.....	34
Polygon turning unit i=1	35
Polygon turning unit i=5.....	36
Polygon turning unit i=7	37
Rear end machining unit i=0,5.....	38
Rear end machining unit i=0,5538847 (221:399)	39

Tool holder selection



For more information, please visit our iXshop at ixshop.index-traub.com

We will be happy to send you an individual offer.
Just call us at +49 711 3191-9854 or
send us an email to werkzeughalter@index-werke.de.

Warranty



When using tool holders that are not adjusted, tested and marked as such by INDEX TRAUB, the warranty for the tool drive is void.

Information on wear parts

Tool holders are wear parts requiring correct handling.
In order to ensure a long service life, compressed air or coolant must not enter the gap seals of the holders.

Inspection of live tool holders



Tool holders must be inspected at regular intervals (at least twice a year) for smooth running and play.



The drive pinion and drive clutch of the live tool holders must be subjected to a visual inspection for damage or wear.

If one of the above-mentioned defects is detected during the inspection of the tool holders, they must be returned immediately for preventive maintenance or repair to the following address:

INDEX-Werke GmbH & Co. KG
Hauffstraße 4
D-73262 Reichenbach
Fon +49 711 3191-554
werkzeughalter@index-werke.de

Tool holders with cooling lubricant supply



Tool holders marked with this symbol must be operated with cooling lubricant (no dry running permitted).




Tool holders marked with this symbol can be converted from external cooling lubricant supply to internal cooling lubricant supply.

Observe dry running capability of IC attachment!

Cooling lubricant filtering

When using live tool holders with internal cooling lubricant supply, it is necessary to use a cooling lubricant filter system with a retained particle size $\leq 50 \mu\text{m}$.

Cleaning live tool holders



Live tool holders must never be immersed in cleaning fluid since mixing the cleaning fluid with the bearing grease will reduce the service life of the tool holders.

Speed ratio specifications on tool holders

The value to be programmed is specified in the documentation and on the live tool holders (= the input in the NC program).

$$n_{\text{prog}} = n_{\text{Tool}} \times i$$

n_{Tool} = speed at the cutting tool edge

n_{PROG} = speed to be programmed

i = speed ratio in the tool holder

This means the speed increase or speed reduction is not specified as a fraction but as **a number**.

This gives speed **increase** ratios as numbers **less than 1**.

Example: $i = 0.333$ (corresponds to $i = 1:3$)

$i = 0.676$ (corresponds to $i = 1:1.48$)

Speed reduction ratios are numbers greater than 1.


Example: $i = 2$ (corresponds to $i = 2:1$)

$i = 1.333$ (corresponds to $i = 4:3$)

Direction of rotation specification

Definition of the viewing direction.

Viewing direction for determining the direction of rotation is always from behind (that is, from the drive direction) toward the shaft.



On the machine side, the direction of rotation has been set by parameters such that M03 always denotes clockwise rotation and M04 counter-clockwise rotation at the interface of the drive pinion of the tool holder.

The direction of rotation given on the holder therefore refers to a "change in direction within the holder". M03 and M04 are machine functions to be programmed. The and arrows indicate the direction of rotation of the cutting edges.

This means:



No reversal of direction of rotation

When the holder drive shaft has the **same** direction of rotation as the tool cutting edge, the clockwise direction of run must be specified by M03 (clockwise rotation). Accordingly, counter-clockwise rotation must be specified by M04.




Reversal of direction of rotation

When the holder drive shaft has the **opposite** direction of rotation as the tool cutting edge, the clockwise direction of rotation must be specified by M04. Accordingly, counter-clockwise rotation must be specified by M03.

Example

No reversal of direction of rotation



Tightening torque

The tightening torques of the clamping pieces to the tool holder mounting depends on the shank diameter of the tool holder.

Shank size	Tightening torque
Ø 20mm	8 Nm
Ø 25mm	20 Nm
Ø 30mm	25 Nm
Ø 40mm	40 Nm

Replacement seals for tool shank

The gaskets on the tool shank and the cooling lubricant bushing must be regularly checked for damages.

O-ring	O-ring color	Material number	Installation location
ø23.52 x 1.78	Green	10823023	Shank ø25
ø9.75 x 1.78	Green	10046965	Cooling lubricant adapter

The color of the reordered O-ring must always be the same as the one already used on the tool shank.

Tool holders with fixation



Except for very few cases, all tool holders have been pre-adjusted with high precision and sealed with the INDEX V bar / TRAUB adjusting bar / W-serration.

This setting must not be changed.

The INDEX V bar / TRAUB adjusting bar / W-serration ensures positional accuracy of the tool when re-inserted.

The tool holders are fixed around the shank axis by pins (DIN 69880).

DIN holders can be used.

Double serration of the tool holders allows several uses.

Load limits of live tools

The drive power and torques are indicated in the performance charts. These values represent the upper limit of the calculated theoretical performance values (average values). In case of interrupted cuts, e.g., for milling, the load peaks occurring when the cutting edge enters the material may be much higher than the theoretical torque according to the performance chart.



The cutter should be selected so that a cutting edge is constantly being used for cutting during the machining process.


Notes on how to use the chart when using tool holders

The diagram relates to the output speed n of the tool unit. The tool speed can be read directly from the diagram only if the internal speed ratio i in the tool holder is 1:1.

For tool holders with an internal speed ratio $i \neq 1$, the output speed n of the tool unit to be programmed must be calculated from the required tool speed and the speed ratio i . Afterwards, the actual powers or torques can be read off or determined.

Example (at 100% duty cycle):

live tool unit, tool speed $n_{\text{tool}} = 1000 \text{ rpm}$	
Internal speed ratio i of the tool holder	$i = 4$
Programmed speed n_{prog} for the drive of the unit	$n_{\text{prog}} = n_{\text{tool}} \times i = 1000 \text{ rpm} \times 4 = 4000 \text{ rpm}$
Torque M_{tool} at the output of the tool holder	Read-out M_d at speed $n_{\text{prog}} = 4000 \text{ rpm} = 1.6 \text{ Nm}$ $M_d = M_{\text{tool}} : i$ Formula changed: $M_{\text{Tool}} = M_d \times i = 1.6 \text{ Nm} \times 4 = 6.4 \text{ Nm}$
Power P at the output of the tool holder \approx Power P at the output of the setup	Read-out at 4000 rpm $\rightarrow P = 0.67 \text{ kW}$ calculated: $P = 2 \times \pi \times n_{\text{prog}} \times M_d$ $P = 2 \times \pi \times 4000 \times 1.6 \text{ Nm} = 0.67 \text{ kW}$ 60×1000




The speed ratio and the technical data of each tool holder are indicated on the next pages.

Machine concept of the INDEX MS22-6

Full equipment with one synchronous spindle

Machining with six spindles




- 12 tool carriers with 1 or 2 axes
- Rear end machining unit with 3 tools, max. 2 live
- Multiple tooling of the cross slide unit optional
- Only the tool holders determine the machining direction (internal or external)
- Transverse machining with driven tools
- Cut-off side machining with up to 6 tools in total
- NCU (Numerical Control Unit) Control unit within the CNC control


Machine concept of the INDEX MS22-6

Full equipment with two synchronous spindles


**Double three-spindle machining or
six-spindle machining with simultaneous rear-end machining in two spindle positions**




- 12 tool carriers with 1 or 2 axes
- 2 swiveling synchronous spindles
- 2 rear end machining units with 3 tools of which max. 2 are live
- Multiple tooling of the cross slide unit optional
- Only the tool holders determine the machining direction (internal or external)
- Transverse machining with driven tools throughout
- NCU (Numerical Control Unit) Control unit within the CNC control

Travel of cross slide unit INDEX MS22-6**Cross slide unit X-NC 1.1 - 6.2**

S = travel of cross slide unit

Travel of cross slide unit INDEX MS22-6**Cross slide unit X-rigid 1.1, 1.2, 2.1**

S = travel of cross slide unit

Travel of cross slide unit INDEX MS22-6**Cross slide unit X-hydraulic 1.1, 1.2, 2.1**


S = travel of cross slide unit

X	Basic holder, double
34,0 mm	10918415
45,5 mm	10311030


Synchronized spindle INDEX MS22-6

Synchronous spindle with parts removal 6.1, 5.2

Rear end machining unit on cross slide unit 6.2, 6.3, 5.1, 5.3





S = travel of cross slide unit

Synchronized spindle INDEX MS22-6**Synchronous spindle with parts removal 6.1, 5.2****Rear end machining unit on cross slide unit 6.2, 6.3, 5.1, 5.3**

Y axis INDEX MS22-6

Attachable to cross slide unit 3.1, 4.1, 5.1

 $\alpha=0.93337^\circ$ per motor revolution













Tool drive unit shank VDI20, INDEX MS22-6**Cross slide unit 1.1 - 6.2****Installation size**


1-4 = pair of screws

5 = slot nut

I, II, III = slide slot

Tool drive unit shank VDI20, INDEX MS22-6**Cross slide unit 1.1 - 6.2****Installation size**

Basic dimension B	slot nut 10223322 used in the cross-slot unit slot	used pairs of screws
-45,4 mm		
-30,4 mm		
-15,4 mm		
-15,4 mm		
-0,4 mm		
+14,6 mm		

Tool drive unit shank VDI25, INDEX MS22-6**Cross slide unit 1.1 - 6.2****Installation size**


1-4 = pair of screws

5 = slot nut


I, II, III = slide slot

Tool drive unit shank VDI25, INDEX MS22-6**Cross slide unit 1.1 - 6.2****Installation size**

Basic dimension B	slot nut 10223322 used in the cross-slot unit slot	used pairs of screws
-43,5 mm		
-28,5 mm		
-13,5 mm		
-13,5 mm		
+1,5 mm		
+16,5 mm		

Cross slide unit INDEX MS22-6**X-NC 1.1 - 6.2**


I, II, III = slide slot

Modular design of INDEX MS22-6**Grooving tool holder****Cross slide unit 1.1 - 6.2, machining in X/Z direction**


1 Cross slide unit 1.1 - 6.2

2 Intermediate plate as needed


3 Grooving tool holder

Modular design of INDEX MS22-6**Base holder with drill holder D28,5mm****Cross slide unit 1.1 - 6.2, machining in X/Z direction**


- 1 Cross slide unit 1.1 - 6.2
- 2 Intermediate plate as needed
- 3 Base holder
- 4 Drill holder ø28,5mm

Modular design of INDEX MS22-6**Milling tool holder****Cross slide unit 1.1 - 6.2, machining in X/Z direction**

- 1 Cross slide unit 1.1 - 6.2
- 2 Intermediate plate as needed
- 3 Milling tool holder
- 4 Quick-change insert INDEX TRAUB CAPTO

Modular design of INDEX MS22-6**Milling unit, shank HSK25C****Cross slide unit 1.1 - 6.2, machining in X/Z direction**

- 1 Cross slide unit 1.1 - 6.2
- 2 Intermediate plate as needed
- 3 Milling unit
- 4 Tool holders HSK25C


Modular design of INDEX MS22-6**Tool drive unit, shank VDI20/VDI25****Cross slide unit 1.1 - 6.2, machining in X/Z direction**

1 Cross slide unit 1.1 - 6.2


2 Intermediate plate as needed

3 Tool drive unit

4 Tool holder VDI20/VDI25

Modular design of INDEX MS22-6**Polygon turning unit****Cross slide unit 1.1 - 6.2, machining in X/Z direction**


- 1 Cross slide unit 1.1 - 6.2
- 2 Polygon turning unit

Modular design of INDEX MS22-6**Rear end machining unit, rigid****Cross slide unit 6.2/5.1, machining in X/Z direction**

1 Cross slide unit 6.2/5.1

2 Rear end machining unit, rigid

3 Mounting, fixed

Modular design of INDEX MS22-6**Rear end machining unit****Cross slide unit 5.3/6.3, machining in X/Z direction**

- 1 Cross slide unit 5.3/6.3
- 2 Rear end machining unit
- 3 Mounting fixed / driven


Performance diagram

Tool drive unit VDI20/VDI25, i=1

Speed range 0-6000rpm



For information on how to use the diagram, see Chapter "Technical Information".




Performance diagram**Milling unit transverse HSK25C, i=0,5**

Speed range 0-12000rpm



For information on how to use the diagram, see Chapter "Technical Information".



Performance diagram


Milling unit axis-parallel, HSK-25C, $i=0,59375$

Milling unit angle-adjustable, HSK-25C, $i=0,6$

Speed range 0-10000rpm



For information on how to use the diagram, see
Chapter "Technical Information".




Performance diagram**Polygon turning unit i=1**

Speed range 0-6000rpm



For information on how to use the diagram, see Chapter "Technical Information".




Performance diagram**Polygon turning unit i=5**

Speed range 0-1200rpm



For information on how to use the diagram, see
Chapter "Technical Information".




Performance diagram**Polygon turning unit i=7**

Speed range 0-857rpm



For information on how to use the diagram, see Chapter "Technical Information".




Performance diagram

Rear end machining unit i=0,5

Speed range 0-12000rpm



For information on how to use the diagram, see Chapter "Technical Information".




Performance diagram

Rear end machining unit i=0,5538847 (221:399)

Speed range 0-10000rpm



For information on how to use the diagram, see Chapter "Technical Information".



INDEX

TRAUB

**INDEX-Werke GmbH & Co. KG
Hahn & Tessky**

Plochinger Straße 92
D-73730 Esslingen

Fon +49 711 3191-0
Fax +49 711 3191-587

info@index-werke.de
www.index-werke.de